

# UNIQUE AUTO CREATIONS

## Universal Canard Install Guide

Tools needed: Blue low tack painters masking tape, something to mark on the paint with, awl or center punch, drill motor, small drill 1/8" or less for pilot hole, 3/16" drill, Phillips screwdriver, 11/32 wrench or socket

1. Pick an area on the car where you would like to mount your canards. Make sure there is nothing behind it that will interfere with drilling the mounting holes or the mounting hardware once installed
2. Hold the canard up to the car and mask off the area around the mounting tabs. Masking tape should help keep the paint from chipping while drilling
3. Position canards on the car where you decided and tape into place
4. Mark the hole locations in all the mounting tabs
5. Make a small indentation with your center punch or awl in the center of the holes you just marked. This should keep your drill from walking
6. Drill a small hole with your pilot drill in the center of your marks
7. Drill pilot holes out to 3/16
8. Deburr edges of the holes if needed
9. Bolt canards in place with the supplied hardware. This may require removal of fender liners or plastic paneling under the car for access to the back side of the fenders / bumper.
10. Enjoy!

---

**Disclaimer:** Unique Auto Creations is not responsible for damage to your car / paint due to installation of this product. Buyer assumes all liability. Professional installation is recommended.