

Winglets Using Factory Mounting Bolts Installation Guide

Tools needed: Wrench set

1. Carefully lift the front of the car. Ramps are OK. If using a jack, make sure to use stands. Always follow the manufacturer's safety instructions.
2. Hold each winglet up to the bottom side of your bumper and align it to the back edge of the bumper cover. Remove the factory mounting bolts that line up with the holes.
3. Place winglet flat against the bottom of the bumper and reinstall the factory mounting bolts.
4. Enjoy!